


# FSI660R and FSI860R Start Up Checklist

## Confirm the following:

- ☐ **Follow the 5'-10'-15' rule on case placement.** *Scan the QR code to view 5'-10'-15' Rule document.*
- ☐ **HVAC Air Vent:** Even if outside of 10', air from a HVAC air vents should not blow air at the case.
- ☐ **Front entrance or door:** The condensing unit air intake (Case Front) should face the front door.
- ☐ **Adjacent equipment:** Ensure that all other equipment's air is not blowing at the Structural Concepts case.
- ☐ **Level the Case Properly:** Make sure the case is properly leveled. *Scan the QR code to view the video instruction.*
- ☐ **Keep the Case Stocked:** This unit is not intended to run without product. Case must be loaded with pre-chilled product for efficient operation.
- ☐ **Turn On All Three Switches:** Ensure all three switches are turned on, this includes main and aux power switch and LED light switch. After the case is turned on, check to ensure that all fans shrouds are in place, all fans are running, and all lights are on
- ☐ **Clean Filters Weekly:** Ensure all four condensing unit filters are cleaned weekly. This filter helps prevent dust particles from entering condenser coil
  - Filters are accessible on the case front (air intake) side of the case.
  - Magnetic condenser coil filter is dishwasher safe; remove from case and use a rag or soft-bristled brush to wipe off excess dust particles from filter. Run in normal dishwasher cycle.
  - Dry with a soft cloth or allow to air dry. Replace in case.
- ☐ **Understand the Thermometer Reading:** The thermometer reflects the air return temperature, which is the warmest air in the case. It does not reflect product temperature.
- ☐ **Check Store Conditions:** Confirm store temperature not to exceed 75°F and relative humidity of 55% for optimal case performance.



## Scan QR Code for the following:

- User Manuals for FSI660R and FSI860R
- Start-Up Video Instruction
- 5'-10'-15' Rule Document
- FSI660R and FSI860R Drawings
- Register your Warranty